

+

|||||

L/R MONITOR Xformer IN

TRIDENT

L/R INSERT ON

SOLO ACTIVE

SOLO LEVEL

MONITOR

2 TRK 1 RETURN

2 TRK 1 RETURN

2 TRK 2 RETURN

SUM MONO

MONITOR LEVEL

MUTE

DIM

ALT MONITOR

HEADPHONE LEVEL

TALKBACK LEVEL

TALKBACK MIC

EXTERNAL MIC

TALK TO GROUPS

TALK TO AUXES

+

5 0 5 10 15 20 25 30 40

+