





GROUP MONITOR METERS



AUXILIARY MASTERS



STEREO FX RET 1 L BAL R LEVEL MUTE	STEREO FX RET 2 L BAL R LEVEL MUTE	STEREO FX RET 3 L BAL R LEVEL MUTE	STEREO FX RET 4 L BAL R LEVEL MUTE	STEREO FX RET 5 L BAL R LEVEL MUTE	STEREO FX RET 6 L BAL R LEVEL MUTE	STEREO FX RET 7 L BAL R LEVEL MUTE	STEREO FX RET 8 L BAL R LEVEL MUTE
---	---	---	---	---	---	---	---

GROUP 1 INSERT ON	GROUP 2 INSERT ON	GROUP 3 INSERT ON	GROUP 4 INSERT ON	GROUP 5 INSERT ON	GROUP 6 INSERT ON	GROUP 7 INSERT ON	GROUP 8 INSERT ON
-------------------	-------------------	-------------------	-------------------	-------------------	-------------------	-------------------	-------------------

PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR	PRE 5 PAN 6 LEVEL MON LEVEL MON PAN SOLO GROUP MONITOR
--	--	--	--	--	--	--	--

